

Introduction

RECALL DESIGNS has developed the ideal tool for achieving your goal: "Capture the most coveted game." Welcome to your new RD-TRONICS device! **RD-TRONICS** (1)

Startup

The new RD-TRONICS has been designed by hunters for hunters. You will notice this when you receive a response from your game and need to act quickly—just press the button thanks to our ergonomic handle equipped with a keyboard in the palm of your hand. Additionally, we have minimized openings on the device because hunting does not always occur in easy conditions. Rain is often a problem with small electronic devices. We have also included a very practical adjustable strap.

The robust ABS handle will last over time without breaking. The resonance cone is made of rubber, reproducing sound with amazing quality.

Your RD-TRONICS also comes with 5 pre-installed sounds. These moose-calling sounds can be changed at your discretion. If you believe your brother-in-law has the best moose "CALL," you can connect to a PC and transfer the desired sounds to the RD-TRONICS (see page 3 for details).

Getting Started:

You must charge the battery of your new RD-TRONICS. Use the provided cable. The charger is compatible with your mobile phone, computer USB port, or even the USB ports installed in most vehicles nowadays.

(1) Patent Pending **RD-TRONICS Version: September 2024**

Usage Instructions

Turning on the RD-TRONICS:

- Press the "Power On" button. The light indicator will turn GREEN for a few seconds, then it will blink as long as the device is active.

Turning off the RD-TRONICS:

- Simultaneously press the "Power On" button and the "Volume Up" button for 3 seconds. The indicator will blink GREEN 3 times, and the device will turn off.

Playing a Sound:


- Press the numbered buttons (1 to 5) according to your choice. To stop playback, press the same button again.

Increasing the Volume:

- Press the "Volume Up" button. You can increase the volume in two ways:
 1. Press and hold for continuous increase.
 2. Press once to raise the volume by 20% each time.
- When the maximum volume is reached, the GREEN light will stop blinking.

Decreasing the Volume:

- Press the "Volume Down" button. You can decrease the volume in two ways:
 1. Press and hold for continuous decrease.
 2. Press once to lower the volume by 20% each time.
- When the minimum volume is reached, the GREEN light will stop blinking.



Usage Instructions

Transfer files via cable:

Here are the steps:

1. Use the cable provided with your RD-TRONICS to connect it to your computer.
2. Open the port that connects to the RD-TRONICS.
3. To verify the connection, the LIGHT INDICATOR should turn turquoise. (If yes, you can proceed.)
4. On your computer screen, a page displaying 5 files should appear. These files are:

track1.mp3
track2.mp3
track3.mp3
track4.mp3
track5.mp3

Now, you should have on your computer the file(s) you want to upload to your RD-TRONICS.

IMPORTANT:

Files must be of the "mp3" type. If not, conversion tools are available to help you.

Once your "mp3" files are selected, rename them according to the order you want for the handle buttons.

Example:

If you have a sound named "Call_a_Jean.mp3" and want to assign it to the BUTTON 'type of sound', position 2, rename it to "track2.mp3". Follow the same process for other buttons you wish to modify.

After preparing your sound choices:

1. Access the RD-TRONICS page displaying the 5 pre-installed sounds.
 2. Rename the button you want to change, e.g., rename "track2.mp3" to "track22.mp3" to preserve it for future use.
 3. Copy and paste your "track2.mp3" file into the RD-TRONICS folder.
- Finally, disconnect the USB-C cable between the RD-TRONICS and your computer.

Your new sounds are ready to use.

RD-TRONICS version September 2024